



**8 Power Street
Levin, 5510
Phone: 06 368.8076
email: mike@sadl.co.nz**

To load PRIME onto a Topfield

- 1.Press 'Menu'
- 2.Highlight 'Installation' and Press OK.
- 3.Enter PIN No.
- 4.Highlight 'Service Search' and Press OK.
- 5.Make sure that both the Level & Quality bars have signal on them.
- 6.Highlight 'Start Search' and Press OK.
- 7.Let it search, once finished Press OK to continue.
- 8.Press exit.
- 9.You will now have Prime

NB. You will need to re-locate Prime to where you want it as per the instructions on page 43 of your manual.